



M Y N A HSM

**Corelabs 8154 Octane Analyzer Driver
Programmable Serial Interface Card
Series 2**

USER MANUAL

Rev. P1.10

February 7 2005

DeltaV is a trademark of Emerson Process Management, Inc © Emerson Process Management, Inc. 1998, 1999.
All rights reserved.

Printed in the U.S.A.

While this information is presented in good faith and believed to be accurate, MYNAH Technologies does not guarantee satisfactory results from reliance upon such information. *Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding the performance, merchantability, fitness or any other matter with respect to the products*, nor as a recommendation to use any product or process in conflict with any patent. MYNAH Technologies reserves the right, without notice, to alter or improve the designs or specifications of the products described herein.



1 INTRODUCTION

1.1 Scope

This document is the User Manual for the Corelabs driver firmware for the Emerson Process Management (EPM) DeltaV Control System; it provides information required to install, configure, and maintain the driver firmware on the DeltaV Series 2 Programmable Serial Interface Card (PSIC). The reader should be familiar with EPM's DeltaV PSIC and connected Corelabs devices.

The section *Document Format* briefly describes the contents of each section of this manual. *System Specifications* outlines hardware and software requirements for the Corelabs Driver (P1.10) firmware. This driver is not available for Series 1 serial cards.

1.2 Document Format

This document is organized as follows:

Table 1

Introduction	Describes the scope and purpose of this document.
Theory of Operation	Provides a general functional overview of the Corelabs Driver.
Downloading Firmware	Describes downloading procedures for the Corelabs Driver firmware on to the DeltaV PSIC.
Configuration Information	Describes procedures and guidelines for configuring the DeltaV PSIC.
Operational Check	Provides tips and assistance to ensure PSIC is properly setup and configured.
DeltaV–Field Device Electrical Interface	Describes the electrical interface between DeltaV and the Corelabs device. Also describes the cable pin assignments for RS-232.
Technical Support	Describes who to call if you need assistance.
Example	Describes how to configure a device with input and output datasets.



1.3 System Specifications

The following table lists the minimum system requirements for the Corelabs Driver:

Table 2

Firmware	Corelabs Driver Firmware (P1.10)
Protocol Compatibility	Customer supplied Corelabs document
Software Requirements	DeltaV System Software (Release 6.3.2 or later) installed on a hardware-appropriate Windows NT or later workstation configured as a ProfessionalPlus for DeltaV Serial Interface Port License (VE4102)
Minimum DeltaV Hardware Requirements	FRSI DeltaV Serial Interface Series 2, Hardware PN: 12P2506X022 FRSI DeltaV M3, M5, MD or Series 2 MD Controller, Power Supply and 2 wide controller carrier FRSI 8 wide I/O card carrier




2 THEORY OF OPERATION

The Programmable Serial Interface Card (PSIC) has 2 ports which can be configured for RS-232, RS-422/RS-485 Half Duplex or RS-422/RS-485 Full Duplex communications with external devices.

The DeltaV Serial Card Driver functionality will be as follows.

1. The driver will be flashed into the PSIC.
2. The driver will run in Slave mode and wait for data to arrive from the Corelabs device. When the first prompt arrives the serial card will take the data from dataset 1 and respond to all 5 prompts. After which, the verification messages sent from the corelabs will be stored in dataset 2.
3. The two ports of the PSIC work independently, each connected to a Corelabs unit.






3 Downloading the firmware

The driver software distribution comprises 13 files, distributed on a CD. These files must be copied to the DeltaV directory on your ProPlus Workstation. The path is:


\\DeltaV\ctl\ProgSerial\S2Corelabs

Note that you will have to create the \S2Corelabs subdirectory. The following files will be copied:







After copy completion, you are ready to program (or upgrade) the Programmable Serial Card with the supplied custom driver software. The steps are as follows:



1. Click on the Start button and select DeltaV-> Installation-> Controller Upgrade Utility as shown below, and the following dialog will appear:




2. Choose Upgrade I/O Modules from the drop down menu and click Next.




3. The above dialog will appear, listing all the available Controllers in your network. From this dialog, select the appropriate Controller and then Click Next.


4. The following dialog will appear, listing all the I/O modules in your selected Controller. The shown list of I/O modules is an example only. Your list will be different.



Note: The first time a standard Serial card is upgraded to the Heise Driver, the dialog will be as shown below. When upgrading an existing Programmable Serial Card, skip Steps 4, 5 and 6, and go to Step 7.




5. Click the Browse button and select the DeltaV path as shown below, and then click Ok. Note that the disk drive could be C or D.






6. Select the I/O module again as shown below and then click Next. Go to Step 9.



7. If you are upgrading an existing Programmable Serial Card, the dialog will be as shown below. From this dialog, select the Programmable Serial Card I/O Module in the list.






For example, we will select I/O Module 1. This will give you a dialog, from which you will select the file path to where the driver software is located. This path will be:

\\DeltaVct1\ProgSerial \S2Corelabs

Once you are in the specified directory, you will need to select the following file:


S2Corelabs.S2F

This is shown in the following dialog.






8. After selecting the .S2F file, Click on Open. This dialog will close and you will be back to the following:




9. In this dialog, Click Next again. You will get the following dialog, confirming the Controller and I/O Module to program.





10. Click Next and the I/O Module upgrade process will begin. After completion, you will receive the following dialog, indicating success.



11. This completes the I/O Module upgrade process.




4 CONFIGURATION INFORMATION

The DeltaV Explorer view of a configuration containing a Programmable Serial Card will be as follows, where C01 has a card type of Programmable Serial Card, P01 and P02 are the ports on the card. The following is the default configuration for use with this driver. Each port will contain 1 device with 2 defined dataset.

Dataset Configuration
Table 3

Port	Devices	Dataset	Mode	Type and Number of Values	Description
P01					
	DEV01				
		DS1	Input	Floating Point, 5 Values	Stores Prompts to send to Corelabs
		DS2	Input	Floating Point, 5 Values	Stores Corelabs Verification Msgs
P02					
		DS1	Input	Floating Point, 5 Values	Stores Prompts to send to Corelabs
		DS2	Input	Floating Point, 5 Values	Stores Corelabs Verification Msgs



4.1 Port Configuration

First, enable the port. Then click on the Advanced Tab and choose slave mode. In slave mode the serial card will wait for data to arrive from the Corelabs and store it in Dataset 1.



Next, click on the Communications Tab and specify the Port type. Lastly, select the Baud rate, Parity, Data bits and Stop bits parameters; these must match the Corelabs settings.

4.2 Device Configuration

Specify devices, as shown above. There will be one device under each port.

4.3 Dataset Configuration

Dataset 1 will contain the Corelabs Prompt Data and Dataset 2 will contain the verification messages.

4.3.1 Data Direction:

Dataset 1 and 2 should be defined as Input.

4.3.2 Output Mode and Readback:

Output mode is not used in this driver and should be left as default. Readback should also not be used.

4.3.3 DeltaV Data Type:

The DeltaV data type should be set as Floating Point for both datasets.

4.3.4 DeviceDataType

DeviceDataType will not be used for this driver and should be left as default.

4.3.5 Data Start Address and Number of Values

Data Start Address will not be used for this driver and should be left as default. Number of values should be set to 5 for both datasets.

4.3.6 Special Data

Special Data values will not be used and should be left as default.



4.3.7 Register Mapping

Registers 1-5 in both dataset map to the corelabs as shown:

Register	Dataset 1	Dataset 2
1	Proto to write out	Proto Verification
2	Prod to write out	Prod Verification
3	Proto Micro to write out	Proto Micro Verification
4	Prod Micro to write out	Prod Micro Verification
5	KI to write out	KI Verification

When the first prompt arrives the serial card will send the proto value stored in dataset 1 register 1. It will continue to send the remaining 4 values as the corelabs requests them. After all 5 have been sent the serial card will wait for the verification messages from the corelabs. As the verification messages arrive they will be stored in dataset 2. These can be used to verify the data was written correctly. After a successful communications process the values in dataset 2 should match the values in dataset 1.



5 Operational Check

5.1 Scope

The following sections provide some assistance to ensure the interface is working properly.

5.2 Verify Hardware and Software Version Number

The user can verify that the Corelabs driver has been installed using the DeltaV Diagnostics tool. The Diagnostics tool will show the Hardware Revision No. (HwRev) and the Software Revision No. (SwRev).

To begin the DeltaV Diagnostic tool select Start-> DeltaV-> Operator-> Diagnostics. In the Diagnostics tool expand the Controller, I/O and then double click on the Programmable Serial Interface Card that has the driver installed.

The following information will be displayed:

:	:	:
HwRev	Hardware Revision	1.10 (or later)
SwRev	Software Revision	2.3 (or later)

5.3 Verify Configuration

- Verify port configuration: The serial port must be enabled. User needs to make sure communication settings such as baud rate, parity, and the number of data bits match the field device settings.
- Verify dataset configuration: The datasets configured must be as shown above.

5.4 Verify I/O Communication With Control Studio

User can create I/O modules in the control studio to verify correct values are being written out. An example module is shipped with the distribution. This module shows methods for writing text to the datasets and also how to handle time.

5.5 Using Diagnostics

- Verify PSIC communication: Select the PSIC on Diagnostics and press the right mouse button. Select Display Real -Time Statistics from the drop down menu. If the Programmable Serial Interface Card is functioning then the user will see the Valid Responses counter and the Async and/or Sync Transactions counters incrementing. There will not be any error counting up.



- Verify port statistics: Select the Port on the Programmable Serial Interface Card and press the right mouse button. Then select Display Port Statistics from the drop down menu. Verify that the port communications statistics are being displayed properly and are counting as expected for the protocol's functionality.
- Verify dataset values: Select a dataset and press the right mouse button. Select View Dataset Registers from the Drop down window. Verify that the dataset values are displayed as expected.

5.6 LED Indication

The Yellow LED for the port should be on solid when all communications on that port are valid. The Yellow LED should be blinking if there is some valid communications and some communications with errors on that port. The Yellow LED should be OFF if there are no valid communications on that port.



6 DeltaV–Field Device Electrical Interface

The electrical interface between DeltaV and field devices conforms to the RS-232 and RS-422/485 standards.

Each PSIC has 2 ports, which function independently. The distance between the serial card and the field device can be as much as 5000 feet, per the RS-422/485 standard. When using RS-232, the distance is limited to 50 feet. Section 6.1 shows the pin assignments for the PSIC serial terminal block.

6.1 Pin Assignments for DeltaV PSIC

RS-232 Standard

Table 6

Terminal Number	Signal Description
1	Port 1 - Isolated Ground (GND)
2	Unused
3	Port 1 – Transmit Data (TxD)
4	Unused
5	Port 1 – Receive Data (RxD)
6	Unused
7	Port 1 – Data Terminal Ready (DTR)
8	Port 1 – Data Set Ready (DSR)
9	Port 2 - Isolated Ground (GND)
10	Unused
11	Port 2 – Transmit Data (TxD)
12	Unused
13	Port 2 – Receive Data (RxD)
14	Unused
15	Port 2 – Data Terminal Ready (DTR)
16	Port 1 – Data Set Ready (DSR)



RS-422/485 Half Duplex Standard

Table 7

Terminal Number	Signal Description
1	Port 1 – Isolated Ground (GND)
2	Port 1 - Data +
3	Unused
4	Port 1 - Data -
5	Unused
6	Unused
7	Unused
8	Unused
9	Port 2 – Isolated Ground (GND)
10	Port 2 – Data +
11	Unused
12	Port 2 - Data -
13	Unused
14	Unused
15	Unused
16	Unused

RS-422/485 Full Duplex Standard

Table 8

Terminal Number	Signal Description
1	Port 1 – Isolated Ground (GND)
2	Port 1 – TxD +
3	Unused
4	Port 1 – TxD -
5	Unused
6	Port 1 – RxD +
7	Unused
8	Port 1 – RxD -
9	Port 2 – Isolated Ground (GND)
10	Port 2 – TxD +
11	Unused
12	Port 2 – TxD -
13	Unused
14	Port 2 – RxD +
15	Unused
16	Port 2 – RxD -

6.2 Wiring Connections

For additional DeltaV cabling information, please refer to the DeltaV Books Online documentation. For Corelabs cabling information see appropriate Corelabs documentation.



M Y N A H™

POWERFUL SOLUTIONS FOR DIGITAL PLANTS

7 Technical Support

For technical support or to report a defect, please give Mynah Technologies a call at (636) 681-1555. If a defect is discovered, please document it in as much detail as possible and then fax your report to us at (636) 681-1660.

For Product functionality questions, ask for the people in the following order:

1. David Story
2. Tony Kerr

For Commercial issues, ask for people in the following order:

1. Martin Berutti
2. Jane Wagner

You can also send us your questions via e-mail. Our address is:

support@mynah.com

Thank you for using DeltaV.